



Hydraulic Jacks: Adding Oil

965 Lambrecht Road | Frankfort, IL, 60423

Phone: 866.403.9803 | Fax: 815.469.4705

Email: customerservice@riecotitan.com

www.riecotitan.com

ADDING OIL

RED TRANSMISSION FLUID - ATF

Jacks are ON Camper

Retract jacks all the way **IN**

Remove **fill hole Hex Head Bolt**

Use Syringe to fill up to the bottom of the fill hole

Jacks are OFF Camper

Lay jacks on side

Pour ATF fluid into fill hole

Do not replace hex bolt

Stand up jack to let excess oil to drain out

Replace hex bolt



965 Lambrecht Road | Frankfort, IL, 60423

Phone: 866.403.9803 | Fax: 815.469.4705

Email: customerservice@riecotitan.com

www.riecotitan.com