



**Rieco-Titan Products, Inc.**

**965 Lambrecht Road ♦ Frankfort, IL 60423**

**(815)464-7400 ♦ Fax (815)469-4705**

email: [customerservice@riecotitan.com](mailto:customerservice@riecotitan.com)

[www.riecotitan.com](http://www.riecotitan.com)

Instructions to Manually Crank Interior Roof Lift System

When using the drill to run the roof lift...

- With the drill set to forward, it will lift the roof, reverse to lower it.
- Raise the roof a few inches then run the drill on the motor that is not working to catch up with the others. Continue this process until the roof is fully extended.
  - I suggest that you do not run the corner that you are manually lifting to full capacity.

Sincerely,

*Sue Habegger*

Rieco-Titan Products, Inc

Customer Service

866-403-9803

815-464-7400

Email [customerservice@riecotitan.com](mailto:customerservice@riecotitan.com)